



INSTALLATION INSTRUCTIONS

PQ2220 2" Front Receiver Hitch

Fits Polaris RZR 800, RZR 800-S & RZR 800-4; 2008 -2014

Fits Polaris RZR 570 & RZR 570-S; 2012 – 2022



Tools and Supplies

Small Flat Blade Screwdriver
Polaris Pliers (supplied in factory tool kit)
T-25 Torx Wrench
T-27 Torx Wrench
Towel or Blanket
Ratchet Wrench
9/16" Socket
9/16" Wrench
Electric Drill
3/8" Drill Bit

Installation Instructions

1. Remove Hood
2. Remove diamond-shaped cover plate on front bumper.
3. Unplug headlight harness from headlights.
4. Remove four plastic rivets attaching black plastic bumper cover to the side of the fender (two per side, near yellow reflector decal). These rivets are easily removed and reinstalled. Pry the center pin up slightly using a small flat blade screwdriver. Then use the pliers supplied in the Polaris tool kit to pull the center pin up approx 3/8". If the center pin pulls out of the rivet, this is OK. Remove the complete rivet (center pin & flanged outer part) from the vehicle.



5. Remove six (6) T-27 Torx-head screws from the front of the bumper cover. This will allow you to remove the entire bumper cover. We have found that it is easiest if you remove the top two screws last. We recommend placing an old towel or blanket on the ground so you can set the bumper cover down without scratching it up. Don't use your wife's good towels, or you may never hear the end of it.



6. Position the receiver hitch assembly on the RZR's front frame.
7. Install two (2) supplied 3/8" bolts with flat washers through top of hitch, into existing holes in the frame. Install flat washers & nylon lock-nuts. Do not fully tighten.
8. Holding the receiver hitch assembly tight against the RZR frame, use the two lower mounting holes in the receiver hitch as a guide and mark the frame. Drill two 3/8" diameter holes.

9. Install two (2) supplied 3/8" bolts with flat washers through the hitch, into the holes you just drilled. Install flat washers & nylon lock-nuts and tighten.
10. Tighten top two (2) nylon lock-nuts (previously installed in step #7).
11. Reinstall the plastic front bumper cover, headlight harness and hood in the opposite order from disassembly.

