



PZ10LD / PZ12LD

INSTALLATION INSTRUCTIONS

PZ10LD & PZ12LD Light-Duty 2" Rear Receiver Hitch

(Does NOT fit with some Polaris Rear Bumpers)

Tools and Supplies

Jack & Jack-Stands
Ratchet Wrench
18mm Socket
18mm Combination Wrench

Be certain to observe all safety precautions related to the use of jack-stands throughout the installation of this product.

Installation Instructions

1. Raise the rear of the RZR with a jack so both rear tires are just barely off the ground. Safely support the machine with jack-stands.
2. Remove the radius rod bolts at the four center, vehicle frame locations (arrows in top photo). The factory radius rod plate is removed, and will not be re-used.
3. Install the hitch in place of the factory radius rod plate. Install the factory radius rod bolts, nuts & washers. With all four radius rods re-installed, torque the radius rod bolts to spec (see service manual for your year and model RZR).

TIP: When re-installing the radius rod nuts, apply a couple layers of masking tape on the flats of an open-end wrench so that the nut will be held in the wrench by friction. Slide the nut into this wrench at whatever angle is necessary hold the nut while starting the threads.

4. Remove jack-stands and lower vehicle.



Thunderhawk Performance, Inc.

4456 North Abbe Rd., #138, Sheffield Village, OH 44054 Phone (216) 965-4800